




The people with the solutions that protect you and your environment everyday

Gastec Tube Datasheet

Mercury Vapour Hg

NO. **GAS40**



Performance

Measuring Range	0.05 to 0.25 mg/m ³	0.25 to 6.0 mg/m ³	6.0 to 13.2 mg/m ³
Number of Pump Strokes	5	1	1/2
Correction Factor	1/5	1	2.2
Sampling Time	1.5 minutes per pump stroke		
Detecting Limit	0.01 mg/m ³ (n=5)		
Colour Change	White → Pale Orange		
Reaction Principle	Mercury reacts with Copper Iodide to form Cu-Hg complex, which is pale orange colour. $\text{Hg} + \text{Cu}_2\text{I}_2 \longrightarrow \text{Cu}_2(\text{HgI}_4) + 2\text{Cu}$		
Coefficient of Variation	10% (for 0.25 to 2 mg/m ³), 5% (for 2 to 6 mg/m ³)		
Shelf Life	Up to 3 Years		
Corrections for temperature & humidity	Unnecessary		
Store the tubes at cool and dark place.			

Possible coexisting substances and their interferences

Substance	Concentration	Interference	Change colour by itself
Chlorine	-	Plus error	Produces pale orange stain
Nitrogen Dioxide	-	Plus error	Produces pale orange stain
Hydrogen Sulphide	-	Plus error	Produces pale orange for whole layer of the reagent

Calibration gas generation Vapour pressure method

a1-cbiss Ltd

5 Valiant Way, Lairdside Technology Park, Tranmere, CH41 9HS

www.a1-cbiss.com | sales@a1-cbiss.com | Tel: +44(0)151 666 8300 | Fax: +44(0)151 666 8329

VAT No: 539 5178 13 Company Reg No: 2414633



Certificate No 996
ISO 9001, ISO 14001
OHSAS 18001